GB

RENLIG

Design and Quality
IKEA of Sweden

Contents

Safety information	4	Programmes	15
Safety instructions	5	Consumption values	18
Product description	7	Care and cleaning	19
Control panel	8	Troubleshooting	21
Before first use	11	Technical data	25
Daily Use	11	ENVIRONMENT CONCERNS	26
Hints and tips	14	IKEA GUARANTEE	27

Subject to change without notice.

⚠ Safety information

Before the installation and use of the appliance, carefully read the supplied instructions. The manufacturer is not responsible if an incorrect installation and use causes injuries and damages. Always keep the instructions with the appliance for future reference.

Children and vulnerable people safety

- This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved.
- Do not let children play with the appliance.
- Children of less than 3 years should be kept away unless continuously supervised.
- Keep all packaging away from children.
- Keep all detergents away from children.
- Keep children and pets away from the appliance door when it is open.
- If the appliance has a child safety device, we recommend you activate it.

- Cleaning and user maintenance shall not be made by children without supervision.

General Safety

- Do not change the specification of this appliance.
- Obey the maximum load volume of 7 kg (refer to the “Programme chart” chapter).
- The operating water pressure (minimum and maximum) must be between 0,5 bar (0,05 MPa) and 8 bar (0,8 MPa).
- The ventilation openings in the base (if applicable) must not be obstructed by a carpet.
- The appliance is to be connected to the water mains using the new supplied hose-sets. Old hose sets must not be reused.
- If the supply cord is damaged, it must be replaced by the manufacturer, its Authorised Service Centre or similarly qualified persons in order to avoid a hazard.
- Before maintenance, deactivate the appliance and disconnect the mains plug from the mains socket.
- Do not use water spray and steam to clean the appliance.
- Clean the appliance with a moist soft cloth. Only use neutral detergents. Do not use abrasive products, abrasive cleaning pads, solvents or metal objects.

Safety instructions

Installation

- Remove all the packaging and the transit bolts.
- Keep the transit bolts. When you move the appliance again you must block the drum.
- Always be careful when you move the appliance because it is heavy. Always wear safety gloves.
- Do not install or use a damaged appliance.
- Obey the installation instruction supplied with the appliance.
- Do not install or use the appliance where the temperature is less than 0 °C or where it is exposed to the weather.
- Make sure that the floor where you install the appliance is flat, stable, heat resistant and clean.
- Make sure that there is air circulation between the appliance and the floor.

- Adjust the feet to have the necessary space between the appliance and the carpet.
- Do not install the appliance where the appliance door can not be fully opened.

Electrical connection

- The appliance must be earthed.
- Always use a correctly installed shockproof socket.
- Make sure that the electrical information on the rating plate agrees with the power supply. If not, contact an electrician.
- Do not use multi-plug adapters and extension cables.
- Make sure not to cause damage to the mains plug and to the mains cable. Should the mains cable need to be replaced, this must be carried out by our Authorised Service Centre.
- Connect the mains plug to the mains socket only at the end of the installation. Make sure that there is access to the mains plug after the installation.
- Do not touch the mains cable or the mains plug with wet hands.
- Do not pull the mains cable to disconnect the appliance. Always pull the mains plug.
- Only for UK and Ireland: The appliance has a 13 amp mains plug. If it is necessary to change the fuse in the mains plug, use a 13 amp ASTA (BS 1362) fuse.
- This appliance complies with the E.E.C. Directives.

Water connection

- Make sure not to cause damage to the water hoses.
- Before you connect the appliance to new pipes or pipes not used for a long time, let the water flow until it is clean.
- The first time you use the appliance, make sure that there is no leakage.

Use

⚠ **Warning!** Risk of injury, electrical shock, fire, burns or damage to the appliance.

- Use this appliance in a household only.
- Obey the safety instructions on the detergent packaging.
- Do not put flammable products or items that are wet with flammable products in, near or on the appliance.
- Make sure that you remove all metal objects from the laundry.
- Do not put a container to collect possible water leakage under the appliance. Contact the Authorised Service Centre to ensure which accessories can be used.
- Do not touch the glass of the door while a programme operates. The glass can be hot.

Service

- To repair the appliance contact an Authorised Service Centre.
- Use original spare parts only.

Disposal

⚠ **Warning!** Risk of injury or suffocation.

- Disconnect the appliance from the mains supply.
- Cut off the mains cable and discard it.
- Remove the door catch to prevent children and pets to get closed in the appliance.

Product description

Appliance overview



1 Detergent dispenser drawer
2 Control panel
3 Door opening handle
4 Rating plate
5 Drain filter
6 Adjustable feet

Detergent dispenser drawer



Compartment for detergent used for prewash and soak phase. The prewash and soak detergent is added at the beginning of the wash programme.

Compartment for powder or liquid detergent used for main wash. If using liquid detergent pour it just before starting the programme.

Compartment for liquid additives (fabric softener, starch).

Follow the product manufacturer's recommendations on quantities to use and do not ever exceed the «MAX» mark in the detergent dispenser drawer. Any fabric softener or starching additives must be poured into the compartment before starting the wash programme.

Child safety device

This appliance incorporates a special feature to prevent children and pets becoming trapped inside the drum.
Make sure that children or pets do not climb into the drum. Please check into the drum before using it.



To activate this device, rotate the button clockwise (without pressing it) inside the door until the groove is horizontal. If necessary use a coin.
To disable this device and restore the possibility of closing the door, rotate the button anticlockwise until the groove is vertical.

Control panel

Control panel description



1 Programme knob
2 Display
3 Delay Start button
4 Door lock indicator
5 Start/Pause button
6 Extra Rinse button
7 Easy Iron button
8 Prewash button
9 Option button:
- Super Quick option

- Economy option

10 Spin reduction and Rinse Hold option

Programme knob	It allows you to switch the appliance On/Off and/or to select a programme.
Display 	The display shows the following information: • **A** - Child safety lock This device permits you to leave the appliance unattended during it's functioning. • **B** – Digit: – **Duration of the selected programme**. After selecting a programme, the duration is displayed in hours and minutes (e. g. 2.05). The duration is calculated automatically on the basis of the maximum recommended load for each type of fabric. After the programme has started, the time remaining is updated every minute. – **Delayed start**. The selected delay appears on the display for a few seconds, then the duration of the selected programme is displayed again. The delay time value decreases by one unit every hour and then, when 1 hour remains, every minute. – **Alarm codes**. In the event of operating problems, some alarm codes can be displayed, e. g. E10 (see paragraph «Troubleshooting»). – **Incorrect option selection**. If an option which is not compatible with the set wash programme is selected, the message Err is displayed at the bottom of the display for a few seconds. The integrated red indicator of button ▷|| starts flashing. – **End of programme**. When the programme has finished the flashing zero 0 is displayed, the indicator ⊶ and the indicator of button ▷|| go out. The door can be opened.
Delay Start button	The programme can be delayed from 30 min - 60 min - 90min, 2 hours and then by 1 hour up to a maximum of 20 hours by means of this button.

Door lock indicator	This indicator illuminates when the programme starts and indicates if the door can be opened: • indicator on: the door cannot be opened. The appliance is working or has stopped with water left in the tub. • indicator off: the door can be opened. The programme is finished or the water has been emptied out. • indicator flashing: the door is opening in a few minutes.
Start/Pause button	This button allows you to start or to interrupt the selected washing programme.
Extra Rinse button	This appliance is designed for saving energy. If it necessary to rinse the laundry using an extra quantity of water (extra rinse), select this option. Some additional rinses will be performed. This option is recommended for people who are allergic to detergents, and in areas where the water is very soft. The relevant indicator illuminates.
Easy Iron button	With this option the laundry is gently washed and spun to avoid any creasing. In this way ironing is easier. Furthermore, the appliance will perform some additional rinses in some programmes. On cotton programmes the maximum spin speed is reduced automatically. The related indicator illuminates.
Prewash button	By selecting this option the appliance performs a prewash cycle before the main wash phase. The washing time will be prolonged. This option is recommended for heavily soiled laundry. The relevant indicator illuminates.
Option button	By pressing this button you can set: • **Super Quick option**: the appliance performs a short cycle for lightly soiled items or for laundry which needs only freshening up. We recommend you to reduce the fabric load. The relevant indicator illuminates. • **Economy option**: With this option you can have a good washing results and decrease the energy consumption at the same time. The appliance extends the wash time and reduces the temperature. The related indicator illuminates.

Spin reduction button	By pressing this button you can change the spin speed of the selected programme. The relevant indicator illuminates. **Rinse Hold option** Set this option to prevent the laundry creases. The drum turns regularly to prevent the laundry creases. The relevant indicator illuminates. There is a water in the drum when the programme is completed. The door stays locked. You must drain the water to unlock the door. To drain the water refer to «At the end of the programme».

Before first use

1. Ensure that the electrical and water connections comply with the installation instructions.
2. Remove any material from the drum.
3. Pour 2 liters of water into the main wash compartment of the detergent drawer in order to activate the ECO valve.

Select a cotton cycle at the highest temperature without any laundry in the appliance, to remove any manufacturing residue from the drum and tub.
Pour 1/2 a measure of detergent into the main wash compartment and start the appliance.

Daily Use

Loading the laundry

Open the water tap. Connect the mains plug to the mains socket.

1. Pull the door handle to open the appliance door.
2. Put the laundry in the drum, one item at a time.
3. Shake the items before you put them in the appliance.

Make sure not to put too much laundry in the drum. Refer to max. loads indicated in "Programme chart".

4. Close the door.



Caution!
Make sure that no laundry stays between the seal and the door.

There is a risk of water leakage or damage to the laundry.

Measure out detergent and fabric softener



Pour the detergent into the main wash compartment or in the appropriate compartment if the selected programme/ option it requires (see more details in "Detergent dispenser drawer"). To pour the right quantity of the detergent, see more details in "Degrees of water hardness".



Pour fabric softener into the compartment marked (must not exceed the «MAX» mark in the drawer).

Close the drawer gently

Setting a programme

1. Turn the programme knob to switch the appliance on and set the programme:
   - The indicator of the button flashes.
   - The display shows the programme duration.
2. If necessary, change the spin speed or add available options. When you activate an option, the indicator of the set option comes on.

If you set something incorrect, the display shows the message Err.

For the description of each wash cycle, the compatibility among the washing programmes and the options, consult the chapter «Programmes».

Starting a programme without the delay start

Press the button .

- The indicator of the button stops to flash and stays on.
- The programme starts, the door locks, the indicator is on.
- The programme time decreases with steps of one minute.

The drain pump can operate for a short time at the beginning of the washing cycle.

Starting a programme with the delay start option

1. Press the button again and again until the display shows the delay you want to set. The delay start indicator comes on.
2. Press the button :
   - The door is locked and the indicator is on.
   - The appliance starts the countdown.
   - When the countdown is completed, the programme starts automatically.

You can cancel or change the set of the option before you press the button . After pressing the button you can only cancel the option.

To cancel the option:

a. Press the button to set the appliance to pause. The indicator of button flashes.
b. Press the button until the display shows 0.
Press the button again to start the programme immediately.

Interrupting a programme and changing the options

You can change only some options before they operate.

1. Press the button .
The indicator flashes.
2. Change the options.
3. Press the button again.
The programme continues.

Cancelling a running programme

1. Turn the programme knob to position to cancel the programme and to deactivate the appliance.
2. Turn the programme knob again to activate the appliance. Now, you can set a new washing programme.

Before starting the new programme the appliance could drain the water. In this case, make sure that the detergent is still in the detergent compartment, if not fill the detergent again.

Opening the door

While a programme or the operates, the appliance door is locked. The indicator is on.

Caution! If the temperature and level of the water in the drum are too high and the drum still rotates, you cannot open the door.

To open the door during the first minutes of the cycle or when the operates:

1. Press the button to pause the appliance.
2. Wait until the indicator goes off.
3. You can open the door.
4. Close the door and touch the button again. The programme (or the) continues.

At the end of the programme

- The appliance stops automatically.
- The acoustic signal operates (if it is activated).
- In the display 0 comes on.
- The indicator of the button goes off.
- The door lock indicator goes off.
Turn the programme knob to position to deactivate the appliance.
- You can open the door.
- Remove the laundry from the appliance. Make sure that the drum is empty.
- Close the water tap.
- Keep the door and the detergent drawer ajar, to prevent the mildew and odours.

The washing programme is completed, but there is water in the drum:

- The drum turns regularly to prevent the creases in the laundry.
- The indicator stays on to remind you to drain the water.
- The door lock indicator is on. The indicator of button is off. The door stays locked.
- You must drain the water to open the door.

Draining the water:

1. To drain the water.
   - Set a ⇩ or a ◎ programme.
   - Press the button ▷||. The appliance drains the water and spins.
2. When the programme is completed and the door lock indicator ⊶ goes off, you can open the door.
3. Turn the programme knob to the position ○ to deactivate the appliance.

Stand by

Once the programme has finished, after a few minutes the energy saving system will be enabled. The brightness of the display is reduced. By pressing any button the appliance will come out of the energy saving status.

Hints and tips

Sorting out the laundry

Follow the wash code symbols on each garment label and the manufacturer's washing instructions. Sort the laundry as follows: whites, coloureds, synthetics, delicates, woollens.

Removing stains

Stubborn stains may not be removed by just water and detergent. It is therefore advisable to treat them prior to washing.

Blood: treat fresh stains with cold water. For dried stains, soak overnight in water with a stain remover product then rub in the soap and water.

Oil based paint: moisten with benzine stain remover, lay the garment on a soft cloth and dab the stain; treat several times.

Dried grease stains: moisten with turpentine, lay the garment on a soft surface and dab the stain with the fingertips and a cotton cloth.

Rust: oxalic acid dissolved in hot water or a rust removing product used cold. Be careful with rust stains which are not recent since the cellulose structure will already have been damaged and the fabric tends to hole.

Mould stains: treat with bleach, rinse well (white cottons and fast coloureds only).

Grass: soap lightly and treat with bleach (white cottons and fast coloureds only).

Ball point pen and glue: moisten with acetone[1)], lay the garment on a soft cloth and dab the stain.

Lipstick: moisten with acetone as above, then treat stains with methylated spirits. Treat any residual marks with bleach.

Red wine: soak in water and detergent, rinse and treat with acetic or citric acid, then rinse. Treat any residual marks with bleach.

Ink: depending on the type of ink, moisten the fabric first with acetone[1)], then with acetic acid; treat any residual marks on white fabrics with bleach and then rinse thoroughly.

Tar stains: first treat with stain remover, methylated spirits or benzine, then rub with detergent paste.

1) do not use acetone on artificial silk

Degrees of water hardness

Water hardness is classified in so-called “degrees” of hardness. Information on hardness of the water in your area can be obtained from the relevant water supply company, or from your local authority.

Characteristic	Degrees of water hardness	
	German °dH	French °T.H.
Soft	0-7	0-15
Medium	8-14	16-25
Hard	15-21	26-37
Very hard	> 21	> 37

ⓘ A water softener must be added when water has a medium-high degree of hardness. Follow the manufacturer’s instructions. The quantity of detergent can then always be adjusted (reduced) to degree of hardness soft.

Programmes

Programme Chart

ⓘ Please always refer to the care label symbol of your garment and select the washing programme based on what it says.

Programme Temperature range	Maximum load Maximum spin speed	Programme description (Type of load and soil level)
COTTONS 90° - 60° - 40° - 30°	7 kg 1400 rpm	**White cotton and coloured cotton**. Normal soil and light soil.
+ option COTTONS ECO [1] 60°C - 40°C	7 kg 1400 rpm	**White cotton and colour-fast cotton**. Normal soil. The energy consumption decreases and the time of the washing programme is extended.
SYNTHETICS 60° - 40° - 30°	3 kg 900 rpm	**Synthetic items or mixed fabric items**. Normal soil.
DELICATES 40° - 30°	3 kg 700 rpm	**Delicate fabrics as acrylics, viscose, polyester items**. Normal soil.

Programme Temperature range	Maximum load Maximum spin speed	Programme description (Type of load and soil level)
HANDWASH 40° - 30° - (Cold)	2 kg 1000 rpm	**Delicate fabrics** with "hand washing" care symbol.[2)]
WOOL 40°	2 kg 1000 rpm	**Machine washable wool** and had washable wool[2)].
JEANS 40°	3 kg 1200 rpm	**Items in denim and jersey**. Also for dark coloured items.
20° MIX 20° 20°C	3 kg 900 rpm	Special programme for cotton, synthetic and mixed fabrics with light soil. Set this programme to decrease the energy consumption. Make sure that the detergent is for low temperature in order to have good washing results[3)].
SOAK 30°C	7 kg	Prewash - Soak for about 40 minutes - Stop with water in the tub. Special programme for heavily soiled laundry. At the end of this time the appliance will stop automatically with water left in the tub. Before starting a new washing phase, it is necessary to empty out the water (read "At the end of the programme"). [4)]
30' MINIPROG-RAMME 30°C	3 kg 700 rpm	A short cycle for **synthetics and delicate items with light soil level** or for items to freshen up.
Rinse	7 kg 1400 rpm	To rinse and spin the laundry. **All fabrics**.
Drain	7 kg	To drain the water in the drum. **All fabrics**.
Spin	7 kg 1400 rpm	To spin the laundry and to drain the water in the drum. **All fabrics**.

Programme Temperature range	Maximum load Maximum spin speed	Programme description (Type of load and soil level)
◯ ON/OFF	Position to turn the appliance off or/and reset a programme.	

1) ***Standard programmes for the Energy Label consumption values.*** *According to regulation 1061/2010, these programmes are respectively the «Standard 60°C cotton programme» and the «Standard 40°C cotton programme». They are the most efficient programmes in terms of combined energy and water consumption for washing normally soiled cotton laundry.*

The water temperature of the washing phase may differ from the temperature declared for the selected programme.

2) During this cycle the drum rotates slowly to ensure a gentle washing. If it seems that the drum doesn't rotate or doesn't rotate properly, consider this as a normal functioning of the appliance.

3) The appliance performs the short heating phase if the water temperature is below 20°C. The appliance can show the temperature setting as "cold".

4) This programme cannot be used for very delicate fabrics as silk or wool. Pour the detergent for the soak programme into the compartment marked . At the end of the soak (after having emptied out the water) you can select the desired washing programme. First turn the appliance off, then select the programme and start it.

Programme options compatibility

Programme			1)	2)	3)	4)		
	■	■	■	■	■	■	■	■
	■	■	■	■	■	■	■	■
		■		■	■		■	■
	■	■						■
	■	■						■
	■	■			■	■		■
20°	■	■					■	■
								■
30'								■
	■	■				■	■	■

Programme			1)	2)	3)	4)		
	■							■

1) This option is active only at 40° C and 60° C.

2) When you set this option, we recommend that you decrease the quantity of the laundry. It is possible to keep the full load but the washing results can be unsatisfactory. Recommended load: cotton: 3.5 kg, synthetics and delicates: 1.5 kg.

3) If using liquid detergents, a programme without PREWASH must be selected.

4) Maximum load with Easy iron option 1.5 kg.

Consumption values

The data of this table are approximate. Different causes can change the data: the quantity and type of laundry, the water and ambient temperature.

Programmes	Load (kg)	Energy consumption (kWh)	Water consumption (litre)	Approximate programme duration (minutes)	Remaining moisture (%)[1)]
Cottons 60 °C	7	1.35	67	150	52
Cottons 40 °C	7	0.85	67	140	52
Synthetics 40 °C	3	0.55	42	90	35
Delicates 40 °C	3	0.55	63	65	35
Wool/Handwash 30 °C	2	0.25	55	60	30
Standard cotton programmes					
Standard 60 °C cotton	7	1.01	52	180	52
Standard 60 °C cotton	3.5	0.78	44	149	52
Standard 40 °C cotton	3.5	0.61	44	140	52

1) At the end of spin phase.

Off Mode (W)	Left On Mode (W)
0,10	0,98

Off Mode (W)	Left On Mode (W)
The information given in the chart above are in compliance with the EU Commission regulation 1015/2010 implementing directive 2009/125/EC.	

Care and cleaning

⚠ **Warning!** Refer to Safety chapters.

⚠ **Warning!** Switch the appliance off before you carry out any cleaning or maintenance work.

Maintenance Wash

With the use of low temperature washes it is possible to get a build up of residues inside the drum.

We recommend that a maintenance wash be performed on a regular basis.

To run a maintenance wash:

- The drum should be empty of laundry.
- Select the hottest cotton wash programme.
- Use a normal measure of detergent, must be a powder with biological properties.

Cleaning the dispenser drawer and the drawer recess

The washing powder and additive dispenser drawer should be cleaned regularly.



To remove the drawer, press the catch downwards and pull it out.



To aid cleaning, remove also the top part of the additive compartment.



Use a stiff brush to clean and remove all washing powder residue.



Flush out all the removed parts of the dispenser drawer under a tap to remove any traces of accumulated powder.



Use the previous brush to clean the recess, ensuring that upper and lower part of it is well cleaned.

After having cleaned the dispenser and the drawer recess, replace it and run a rinse programme without any laundry in the drum to flush away any residue.

Cleaning the drain filter

Proceed as follows:



Place a container close to the pump (A), to collect any spillage.



Pull out the emergency emptying hose (B), place it in the container and remove its cover cap.



When no more water comes out, unscrew the filter cover and remove it. Always keep a rag nearby to dry up spillage of water when removing the filter.
Remove any objects from the filter impeller by rotating it.





Use a pencil to check whether the filter wheel right at the back of the filter housing can turn. (It is normal for the filter wheel to turn jerkily.)
If the filter wheel cannot be turned, please contact the Authorised Service Centre.
Put the cap back on the emergency emptying hose and place the latter back in its seat. Screw the filter fully in.



Cleaning the inlet filter and the filter valve

If the appliance takes long to fill with water or doesn't fill, the starting button indicator flashes in red. Check if the water inlet filter and the valve filter are blocked (see chapter "Troubleshooting" for more details).

Proceed as follows:



- Turn off the water tap.
- Unscrew the hose from the tap.
- Clean the filter in the hose with a stiff brush.
- Screw firmly the inlet hose back onto the tap.



- Unscrew the hose from the appliance. Keep a rag nearby because some water may flow.
- Clean the filter in the valve with a stiff brush or with the piece of cloth.



- Screw the hose back to the appliance turning it to the left or the right to suit the installation. Tight the locknut correctly to prevent water leaks.
- Turn on the water tap.

The dangers of freezing

If the appliance is installed in a place where the temperature could drop below 0°C, proceed as follows to remove any water remaining inside the appliance:

- unplug the appliance;
- turn off the water tap;
- place the end of the emergency emptying hose and that of the inlet hose in a bowl placed on the floor and let water drain out;
- screw the water inlet hose back on and reposition the emergency emptying hose after having put the cap on again;
- When you intend to start the appliance up again, make sure that the room temperature is above 0°C.

ⓘ Every time you drain the water through the emergency emptying hose you must pour 2 litres of water into the main wash compartment of the detergent drawer and then run the drain programme. This will activate the ECO VALVE device avoiding that part of the detergent remains unused at next washing.

Emergency emptying out

If the water is not discharged, proceed as follows to empty out the appliance:

- unplug the appliance;
- turn off the water tap;
- if necessary, wait until the water has cooled down;
- open the filter door;
- place a bowl on the floor and place the end of the emergency emptying hose into the bowl. Remove its cap. The water should drain by gravity into the bowl. When the bowl is full, put the cap back on the hose. Empty the bowl. Repeat the procedure until water stops flowing out;
- clean the filter if necessary as previously described;
- replace the emergency emptying hose in its seat after having plugged it;
- screw the filter cover again and close the door.

Troubleshooting

⚠ **Warning!** Refer to Safety chapters.

Introduction

The start of the appliance does not occur or it stops during operation.

With some problems, it is also possible that the **red** indicator of button ▷|| flashes.
First try to find a solution to the problem (refer to the table). If not, contact the Authorised Service Centre.

⚠ **Warning!** Deactivate the appliance before you do the checks.

Possible failures

Problem	Possible cause	Solution
The appliance does not start:	The door has not been closed. (The red indicator of button ▷|| flashes).	Close the door firmly.
	The plug is not properly inserted in the power socket.	Insert the plug into the power socket.
	There is no power at the socket.	Please check your domestic electrical installation.
	The main fuse has blown.	Replace the fuse.
	The programme selector dial is not correctly positioned and the button ▷|| has not been pressed.	Please turn the selector dial and press the button ▷|| again.
	The delay start has been selected.	If the laundry are to be washed immediately, cancel the delay start.

Problem	Possible cause	Solution
The appliance does not fill the water:	The water tap is closed. (The red indicator of button ▷|| flashes).	Open the water tap.
	The water tap is blocked or there is lime scale.	Clean the water tap.
	The connection of the water inlet hose in not correct.	Check the inlet hose connection.
	The water pressure is too low.	Contact your local water authority.
	The inlet hose is squashed or kinked. (The red indicator of button ▷|| flashes).	Check the inlet hose connection.
	The filter in the inlet hose or the inlet valve filter are blocked. (The red indicator of button ▷|| flashes).	Clean the water inlet filters. (See "Cleaning the inlet hose and the valve filter" for more details).
	The door is not properly closed. (The red indicator of button ▷|| flashes).	Close the door firmly.
The appliance does not drain the water:	The drain hose is squashed or kinked. (The red indicator of button ▷|| flashes).	Check the drain hose connection.
	The drain filter is clogged. (The red indicator of button ▷|| flashes).	Clean the drain filter.
	An option or a programme that ends with the water still in the tub or a that eliminates all the spinning phases has been selected.	Select the draining or spinning programme.
	The connection of the drain hose is not correct.	Check the drain hose connection.

Problem	Possible cause	Solution
The appliance switches off during the washing phase:	The mains supply has been cut off.	Wait for the electricity restore. The appliance will start again from the same interrupted washing phase.
The appliance spinning phase starts late or does not start:	The electronic unbalance detection device has cut in because the laundry is not evenly distributed in the drum. The laundry is redistributed by reverse rotation of the drum. This may happen several times before the unbalance disappears and normal spinning can resume. If, after 10 minutes, the laundry is still not evenly distributed in the drum, the appliance will not spin.	Redistribute the load manually or load more laundry and select the spin programme.
There is water on the floor:	Too much detergent or unsuitable detergent (creates too much foam) has been used.	Reduce the detergent quantity or use another one.
	Check whether there are any leaks from one of the inlet hose fittings. It is not always easy to see this as the water runs down the hose; check if it is damp.	Check the water inlet hose connection.
	The drain or inlet hose is damaged.	Replace it with a new one (check with the Authorised Service Centre the right spare part number).
The door does not open:	The programme is still running.	Wait the end of washing cycle.
	The door lock has not been released.	Wait a few minutes before opening the door.
	There is water in the drum.	Select drain or spin programme to empty out the water.

Problem	Possible cause	Solution
The appliance produces an unusual noise:	The transit bolts and packing have not been removed.	Check the correct installation of the appliance.
	The support feet have not been adjusted.	Check the correct levelling of the appliance.
	The drain filter could be blocked.	Check the drain filter. (See "Cleaning the drain filter" for more details).
Unsatisfactory washing results:	Too little detergent or unsuitable detergent has been used.	Increase the detergent quantity or use another one.
	Stubborn stains have not been treated prior to washing.	Use commercial products to treat the stubborn stains.
	The correct temperature was not selected.	Check if you have selected the correct temperature.
	Excessive laundry load.	Reduce the laundry load in according to the washing programmes table.

Service

We recommend the use of original spare parts. After the check, switch on the appliance and press the button ▷|| to restart the programme.

If the problem remains, contact your Authorised Service Centre.

Model description

(MOD): .....

Product number (PNC): .....

Serial number (S.N.): .....

The necessary data for the service centre is on the rating plate. We recommend that you write the data here:



Technical data

Product type	Built in - Washing Machine

Dimensions	Width (cm)	59,6
	Height (cm)	82
	Depth (cm)	54,4 max
Water supply pressure[1)]	Minimum	0,5 bar (0,05 MPa)
	Maximum	8 bar (0,8 MPa)
Cotton max. load (kg)		7
Max. spin speed (rpm)		1400
Energy class		A++
Washing class		A
Spinning class		B
Washing noise (dB(A))		56
Spinning noise (db(A))		74
Average annual energy consumption (kWh)[2)]		189
Average annual water consumption (litres)[2)]		10469

1) If the pressure in your area is lower or higher, please contact your Authorised Service Centre.
2) The data is based on the Standard Cotton programmes for test institutes assuming 200 cycles per a year.

Information on the electrical connection, voltage and overall power is given on the rating plate, on the inner edge of the appliance door.

ENVIRONMENT CONCERNS

Recycle the materials with the symbol ♺. Put the packaging in applicable containers to recycle it. Help protect the environment and human health and to recycle waste of electrical and electronic appliances. Do not dispose appliances marked with the symbol with the household waste. Return the product to your local recycling facility or contact your municipal office.

IKEA GUARANTEE

How long is the IKEA guarantee valid?

This guarantee is valid for five (5) years from the original date of purchase of Your appliance at IKEA, unless the appliance is named LAGAN in which case two (2) years of guarantee apply. The original sales receipt is required as proof of purchase. If service work is carried out under guarantee, this will not extend the guarantee period for the appliance,

Which appliances are not covered by the IKEA five (5) years guarantee?

The range of appliances named LAGAN and all appliances purchased in IKEA before 1st of August 2007

Who will execute the service?

IKEA service provider will provide the service through its own service operations or authorized service partner network.

What does this guarantee cover?

The guarantee covers faults of the appliance, which have been caused by faulty construction or material faults from the date of purchase from IKEA. This guarantee applies to domestic use only. The exceptions are specified under the headline "What is not covered under this guarantee?" Within the guarantee period, the costs to remedy the fault e.g. repairs, parts, labour and travel will be covered, provided that the appliance is accessible for repair without special expenditure. On these conditions the EU guidelines (Nr. 99/44/EG) and the respective local regulations are applicable. Replaced parts become the property of IKEA.

What will IKEA do to correct the problem?

IKEA appointed service provider will examine the product and decide, at its sole discretion, if it is covered under this guarantee. If considered covered, IKEA service provider or its authorized service partner through its own service operations, will then, at its sole discretion, either repair the defective product or replace it with the same or a comparable product.

What is not covered under this guarantee?

- Normal wear and tear.
- Deliberate or negligent damage, damage caused by failure to observe operating instructions, incorrect installation or by connection to the wrong voltage, damage caused by chemical or electro-chemical reaction, rust, corrosion or water damage including but not limited to damage caused by excessive lime in the water supply, damage caused by abnormal environmental conditions.
- Consumable parts including batteries and lamps.
- Non-functional and decorative parts which do not affect normal use of the appliance, including any scratches and possible color differences.
- Accidental damage caused by foreign objects or substances and cleaning or unblocking of filters, drainage systems or soap drawers.
- Damage to the following parts: ceramic glass, accessories, crockery and cutlery baskets, feed and drainage pipes, seals, lamps and lamp covers, screens, knobs, casings and parts of casings. Unless such damages can be proved to have been caused by production faults.
- Cases where no fault could be found during a technician's visit.
- Repairs not carried out by our appointed service providers and/or an authorized

service contractual partner or where non-original parts have been used.
- Repairs caused by installation which is faulty or not according to specification.
- The use of the appliance in a non-domestic environment i.e. professional use.
- Transportation damages. If a customer transports the product to their home or other address, IKEA is not liable for any damage that may occur during transport. However, if IKEA delivers the product to the customer's delivery address, then damage to the product that occurs during this delivery will be covered by this guarantee.
- Cost for carrying out the initial installation of the IKEA appliance. However, if an IKEA service provider or its authorized service partner repairs or replaces the appliance under the terms of this guarantee, the service provider or its authorized service partner will re-install the repaired appliance or install the replacement, if necessary.

This restriction do not apply to fault-free work carried out by a qualified specialist using our original parts in order to adapt the appliance to the technical safety specifications of another EU country.

How country law applies

The IKEA guarantee gives You specific legal rights, which covers or exceed local demands. However these conditions do not limit in any way consumer rights described in the local legislation

Area of validity

For appliances which are purchased in one EU country and taken to another EU country, the services will be provided in the framework of the guarantee conditions normal in the new country. An obligation to carry out services in the framework of the guarantee exists only if the appliance complies and is installed in accordance with:

- the technical specifications of the country in which the guarantee claim is made;
- the Assembly Instructions and User Manual Safety Information;

The dedicated After Sales Service for IKEA appliances:

Please do not hesitate to contact IKEA After Sales Service to:

1. make a service request under this guarantee;
2. ask for clarification on installation of the IKEA appliance in the dedicated IKEA kitchen furniture. The service won't provide clarifications related to:
   - the overall IKEA kitchen installation;
   - connections to electricity (if machine comes without plug and cable), to water and to gas since they have to be executed by an authorized service engineer.
3. ask for clarification on user manual contents and specifications of the IKEA appliance.

To ensure that we provide you with the best assistance, please read carefully the Assembly Instructions and/or the User Manual section of this booklet before contacting us.

How to reach us if You need our service

Please refer to the last page of this manual for the full list of IKEA appointed contacts and relative national phone numbers.

In order to provide You with a quicker service, we recommend that You use the specific phone numbers listed at the end of this manual. Always refer to the numbers listed in the booklet of the specific appliance You need an assistance for. Before calling us, assure that You have to hand the IKEA article number (8 digit code) for the appliance of which you need our assistance.

SAVE THE SALES RECEIPT! It is Your proof of purchase and required for the guarantee to apply. Note that the receipt reports also the IKEA article name and number (8 digit code) for each of the appliances you have purchased.

Do You need extra help?

For any additional questions not related to After Sales of your appliances, please contact our nearest IKEA store call centre. We recommend you read the appliance documentation carefully before contacting us.

Country	Phone number	Call Fee	Opening time
België	070 246016	Binnenlandse gesprekskosten	8 tot 20 Weekdagen
Belgique		Tarif des appels nationaux	8 à 20. En semaine
България	00359888164080 0035924274080	Такса за повикване от страната	От 9 до 18 ч в работни дни
Česká republika	246 019721	Cena za místní hovor	8 až 20 v pracovních dnech
Danmark	70 15 09 09	Landstakst	man. - fre. 09.00 - 20.00 lør. 09.00 - 16.00 1 søndag pr. måned, normalt første søndag i måneden
Deutschland	+49 1806 33 45 32*	* 0,20 €/Verbindung aus dem Festnetz max. 0,60 €/Verbindung aus dem Mobilfunknetz	8 bis 20 Werktage
Ελλάδα	211 176 8276	Υπεραστική κλήση	8 έως 20 κατά τις εργάσιμες ημέρες
España	91 1875537	Tarifa de llamadas nacionales	De 8 a 20 en días laborables
France	0170 36 02 05	Tarif des appels nationaux	9 à 21. En semaine
Hrvatska	00385 1 6323 339	Trošak poziva 27 lipa po minuti	radnim danom od ponedjeljka do petka od 08:00 do 16:00
Ireland	0 14845915	National call rate	8 till 20 Weekdays
Ísland	5880503	Innanlandsgjald fyrir síma	9 til 18. Virka daga
Italia	02 00620818	Tariffa applicata alle chiamate nazionali	dalle 8 alle 20 nei giorni feriali
Κυπρος	22 030 529	Υπεραστική κλήση	8 έως 20 κατά τις εργάσιμες ημέρες
Lietuva	5 230 06 99	Nacionalinių pokalbių tarifai	Pr. - Ketv.: 8:00 - 12:00, 12:45 - 17:00 Pnkt.: 8:00 - 12:00, 12:45 - 15:45
Magyarország	061 998 0549	Belföldi díjszabás	Hétköznap 8 és 10 óra között
Nederland	0900 235 45 32 en/of 0900 BEL IKEA	15 cent/min., starttarief 4.54 cent en gebruikelijke belkosten	ma - vr 08.00 - 20.00, zat 09.00 - 20.00 (zondag gesloten)
Norge	815 22052	Takst innland	8 til 20 ukedager
Österreich	0810 300486	max. 10 Cent/min.	Mo - Fr 8.00 - 20.00 Uhr
Polska	012 297 8787	Stawka wg taryfy krajowej	Od 8 do 20 w dni robocze
Portugal	211557985	Chamada Nacional	9 às 21. Dias de Semana *excepto feriados
România	021 211 08 88	Tarif apel național	8 - 20 în zilele lucrătoare
Россия	8 495 6662929	Действующие телефонные тарифы	с 8 до 20 по рабочим дням Время московское
Schweiz	031 5500 324	Tarif für Anrufe im Bundesgebiet	8 bis 20 Werktage
Suisse		Tarif des appels nationaux	8 à 20. En semaine
Svizzera		Tariffa applicata alle chiamate nazionali	dalle 8 alle 20 nei giorni feriali
Slovensko	(02) 3300 2554	Cena vnútroštátneho hovoru	8 až 20 v pracovných dňoch
Suomi	030 6005203	Lankapuhelinverkosta 0,0835 €/puhelu + 0,032 €/min Matkapuhelinverkosta 0,192 €/min	arkipäivisin 8.00 - 20.00
Sverige	0775 700 500	lokalsamtal (lokal taxa)	mån-fre 8.30 - 20.00 lör-sön 9.30 - 18.00
Türkiye	212 244 0769	Ulusal arama ücreti	Hafta içi saat 09:00'dan 18:00'a kadar
Україна	044 586 2078	Міжміськи дзвінки платні	9 - 21 В робочі дні
United Kingdom	020 3347 0044	National call rate	9 till 21. Weekdays
Slovenija	www.ikea.com		
Србија	www.ikea.com		

132901780-A-082015

CE

© Inter IKEA Systems B.V. 2015

21552

AA-1609380-1